



2-01, 02, 06 TRANSAXLE



2-01, 02, 06 TRANSAXLE

NO	PART NAME	PART NO	Q'TY	REMARK
1 ~59	Transaxle Ass'y (A)	GG1-201012	1	#A004331 and Above
1 ~59	Transaxle Ass'y (Old-Type)	GG1-201010	1	Up to #A004330
1	Carrier Housing		1	
2	Cover, For Carrier		1	
3	Cover, For Rear	GG1-201130	1	
4	Differential Case Ass'y	GG1-201140	1	
5	Spacer, Flat	GG1-201150	2	
6	Washer, Nylon	GG1-201162	1	
7	Bushing, Governor Shaft	GG1-201172	1	
8	Clip, Shift	GG1-201180	2	
9	Shift Rod Ass'y	GG1-201190	1	Includes #8
10	Gasket, Carrier (A)	GG1-201202	1	#A004331 and Above
	Gasket, Carrier (Old)	GG1-201200		Up to #A004330
11	Ball Bearing	GC1-201210	2	
12	Actuator, Rotary	GG1-201220	1	
13	Dowel Pin	GG1-201230	2	
14	Washer, Nylon	GG1-201240	1	
15	Snap Ring	GG1-201250	1	
16	Gear Ass'y, Reverse	GG1-201260	1	
17	Gear Ass'y, Forward	GG1-201270	1	
18	Bushing, Shifter	GG1-201280	1	
19	Idle Shaft	GG1-201290	1	
20	Gear Ass'y, Idler	GG1-201300	1	
21	Snap Ring	GG1-201310	1	
22	Gear Clutch	GG1-201320	1	
23	Actuator Ass'y, Governor (A)	GG1-201332	1	#A004331 and Above
	Actuator Ass'y, Governor (Old)	GG1-201330		Up to #A004330
24	Intermediate Shaft	GG1-201340	1	


2-01, 02, 06 TRANSAXLE



2-01, 02, 06 TRANSAXLE

NO	PART NAME	PART NO	Q'TY	REMARK
25	Input Shaft	GG1-201350	1	
26	Intermediate Gear (A) Intermediate Gear (Old)	GG1-201362 GG1-201360	1	#A004331 and Above Up to #A004330
27	Snap Ring	GG1-201372	2	
28	Oil Seal (A) Oil Seal (Old)	GG1-201382 GG1-201380	1	#A004331 and Above Up to #A004330
29	Oil Seal	GG1-201390	1	
30	Oil Seal	GG1-201400	2	
31	Oil Seal	GG1-201410	1	
32	Washer, Plane			
33	Bolt, Flange Head	GG1-201432	7	
34	Ball Bearing	GG1-201440	1	
35	Ball Bearing	GC1-201450	3	
36	Ball Bearing	GC1-201460	2	
37	Ring Gear (A) Ring Gear (Old)	GC1-201736 GG1-201470	1	#A004331 and Above Up to #A004330
38	Nut	GC1-201480	4	
39	Bolt	GC1-201490	4	
40	Weight, Governor (A)	GG1-201502	3	
41	Plate, Governor	GG1-201512	1	
42	Sleeve, Governor	GG1-201522	1	
43	Washer, Thrust	GG1-201530	2	
44	Thrust Bearing	GG1-201540	1	
45	Washer, Thrust	GG1-201550	2	
46	Ball, Detent	GG1-201560	1	
47	Snap Ring	GG1-201572	1	
48	Sealant, Cover Plate	GC1-201580	1	
49	Spring, Detent	GG1-201590	1	

2-01,02,06 TRANSAXLE



2-01, 02 06 TRANSAXLE

NO	PART NAME	PART NO	Q'TY	REMARK
50	Set Screw	GG1-201602	1	
51	Axle Shaft (L/H)	GG1-202610	1	
52	Axle Shaft (R/H)	GG1-202620	1	
53	Axle Housing (L/H)	GG1-202630	1	
54	Axle Housing (R/H)	GG1-202640	1	
55	Bolt	GG1-201650	8	
56	Bolt	GG1-202660	12	
57	Snap Ring	GC1-202670	4	
58	Vent	GC1-201680	1	
59	Oil Plug	GG1-201690	1	
K1	Gear Set (A)	GG1-211732	1 Set	Includes #16, 17, 20, 22, 26, 37
	Gear Set (Old-Type)	GG1-211730	1 Set	
K2	Housing, Service Ass'y (A)	GG1-211722	1 Set	Includes #1, 2, 10, 13, 18, 32, 33
	Housing, Service Ass'y (Old-Type)	GG1-211720	1 Set	
K3	Bearing Kit, Carrier	GG1-211710	1 Set	Includes #34, 35, 36
K4	Governor Actuator Kit (Old-Type)	GG1-211740	1 Set	Includes #6, 7, 23, 28, 47
K5	Governor Sleeve Kit (Old-Type)	GG1-211750	1 Set	Includes #41, 42
63	Brake Drum	GC1-202330	2	Includes #70
64	Washer	4AJ-000112	2	5/8
65	Axle Nut	2FP-003181	2	5/8-11 UNC
66	Pin , Split	6FG-200100	2	
67	Bolt	1XM-103100	8	M10, L = 16
68	Wheel Nut	GC1-202800	8	M12
69	Wheel & Tire	GC1-507010	2	
70	Wheel Bolt	GC1-504200	8	